



Opening the screen

Double-click the  icon on the desktop or notification area.

Installation procedure

Closing the screen



1. Connect the USB cable.

Click  on the USB cable between the USB downstream port of the computer and the USB upstream port of the monitor (or the USB-C connector if the monitor is equipped with the USB Type-C connector).

2. Double-click "setup.exe", and follow the on-screen instructions to install the software.

Troubleshooting

• The "User Account Control" dialog box may appear. Click "Yes".

Problem	Possible cause and remedy
1. The icon is not in the notification area.	 <p>In Windows 10, select "Start", "All Apps", "EIZO", then click "Screen InStyle" to start the software. In Windows 8.1, click  on the "Start" screen, then click "Apps", "Screen InStyle" to start the software.</p>
2. Screen InStyle does not function according to configured settings.	<ul style="list-style-type: none">• To make the Screen InStyle settings function correctly, the Screen InStyle icon must reside in the notification area.• If you have changed a setting in the page of each function, click "OK". Clicking "OK" applies the setting to the monitor. <p>Change when these notifications appear</p>

• If .NET Framework 4.8 or a later revision is not installed on your computer, the .NET Framework 4.8 installer starts. Follow the on-screen instructions to install. You may be prompted to reboot the computer after the installation is complete.


When the installation is complete, the Screen InStyle icon appears on the desktop and notification area.

Uninstallation procedure

● Windows 10

1. Select "Start", "Settings", "System", then click "Apps & features".
2. Select "Screen InStyle" from the list, then click "Uninstall".
Follow the on-screen instructions to uninstall the software.

● Windows 8.1

1. Click  at the bottom of the "Start" screen.
The "Apps" screen appears.
2. Select "Windows System", "Control Panel", "Programs", then click "Uninstall a program".
3. Select "Screen InStyle" from the list, then click "Uninstall".
Follow the on-screen instructions to uninstall the software.

